


1. General Information


- Please check the system requirements first in order to guarantee a successful FluidMan installation.
- An internet connection is required to install and register FluidMan.
- HAWE TypeMan platform is required in order to work with the schematic configuration interface within TypeGen.
- HAWE TypeMan should always be up to date.

2. FluidMan Installation


- Start the file „HAWE.FluidMan.Setup.exe“ and follow the instructions.




- At the time of registration, please type the serial no. in the associated field (1). Also, please fulfill all mandatory fields. Afterwards, you will get an e-Mail with a registration code. This code is required when you start FluidMan the first time (see point 4 later in this document). This is a single license and is not transferable to other computers.




- Successful registration of your license.



- Please confirm the license agreement.




- Please confirm the system directories.




Above directories are HAWE default settings. These directories are a recommendation. If you have to follow an in-house IT-guideline, you are free to change accordingly.

- Choose the desired language




- Open menu at point 1 and 2
- Choose the desired language package(s) (point 3 and 4)
- Choose the language which should be set at first start of FluidMan (point 5)

➤ Progress of the FluidMan installation




3. Interface Installation

➤ Installation of TypeGen <=> FluidMan interface. Please follow the instructions below.




➤ FluidMan Setup is completed




4. Open FluidMan for the first time

- Start FluidMan (Desktop Icon)
- Choose the license method (Use a validation code)




- Insert the serial no. and the validation code



The validation code (2) you will receive with an E-Mail after a successful registration with the serial no. (1)

- Successful license registration



- Please contact the HAWE support if you have any questions.
- ➔ techsupport (at) hawe.de